FORDPERFORMANCE





February 14, 2025

Technical Service Bulletin – 39


Rear Fascia Mount Repair

Purpose: To support fascia with damaged mounts. This is the only homologated fascia repair allowed.

New parts


Description	QTY	Part Number	Supplier
Quik-Latch Mini, Machined Aluminum	4	QL-25-S	Quik-Latch *
Quik-Latch Mini, Polished Aluminum	4	QL-25-S P	Quik-Latch *
Quik-Latch Mini, Anodized Black	4	QL-25-SB	Quik-Latch *
Quik-Latch Mini, Anodized Red	4	QL-25-RD	Quik-Latch *
Quik-Latch Mini, Anodized Blue	4	QL-25-BU	Quik-Latch *

^{*}All available finishes for the Quik-Latch Mini are legal. Only four Quik-Latches are required per vehicle.



Installation

Remove rear fascia and locate the two round dimples on the rear bumper corner brackets.








Mark and drill the dimples with a 1/8" pilot through the bracket. Continue through the sheet metal, two per side.





Remove brackets from body



Snap bracket onto Fascia and drill 1/8" pilot hole through the fascia



Remove brackets from fascia and open the 1/8" holes to 3/4" $\,$



Open the 1/8" pilot holes in the bracket to $1\ 1/8"$



Open the 1/8" pilot holes in body to 1/4"



Install the four Quik-Latch studs only using a washer on the inside of the body.



Reinstall bracket



Install Quik-Latches on fascia



Reinstall fascia and adjust studs to desired length

